FIRE PIT OPERATING INSTRUCTIONS

The fire pit is located in Ramble Park. Instructions for the fire pit are listed below:

- On the keypad, enter 1,8,8,1
- The pilot in the center of the fire feature will initiate the lighting of the burner. The green led will come on showing that the keypad has turned on the fire. The burner will light after 15 seconds.
- Now you are ready to sit back and enjoy!

SAFETY PROTOCOLS:

- Check wind advisory for high winds. Do not use fire pit if wind levels are higher than 15 miles an hour.
- Do not give out the keypad codes to anyone that does not live in the Canyons community.
- The flame height has been set and cannot be increased or decreased.
- The fire pit will automatically shut off after 15 minutes. You can start the fire pit for another session by entering keypad code.
- DO NOT LEAVE FIRE PIT UNATTENDED WHEN IGNITED.
- Do not use flammable fluids (gasoline, lighter fluid, etc.) to light or relight fire. This is a gas fire pit and ignites automatically when the code is used properly.
- Stay at least 5 feet away from the fire.
- Do not sit on the fire pit ledge.
- Do not play around the fire pit.
- Do not cook or attempt to burn any items in the fire pit.
- Any unauthorized use is subject to action deemed appropriate by the Metro District Board.
- The red button at top is the “Emergency Shut-off Valve”, and is to be used in the event of emergency only. If the button is pressed, the fire pit will revert to a “locked” state and will be inoperable until reset. If the button is pushed, you have to twist it to the right to unlatch it and then power will be restored to the keypad. It will beep for one minute after power is restored and then shut off and be ready for use again.

For questions or concerns, please contact Advance HOA Management at (303) 482-2213